



STARANDDAISY

Sit N Slide


Kids Kick Scooter



Installation and Operational Manual




for safety please read this manual carefully keep it for future reference

NAME OF PARTS






- ① Anti-skid handle bar
- ② Screw cap
- ③ Comfortable Seat
- ④ Rear brake
- ⑤ Light wheel
- ⑥ Lock button

Using without Seat




FOLD AND STORE



THE ASSEMBLY OF SCOOTER

Included Item







Seat Installation




Pull the lock and forcefully straighten up the rod in 90° to the base you will hear the click sound when locked upright.




Use your thumb and pull up the lock



HANDLE INSTALLATION




Height Adjustment



If you want to adjust scooter height first loose the screw cap and then press the spring lock and to to increase height, pull up the rod and to decrease height, press down and lock the rod with the help of spring lock then tighten the screw cap.



Caution: Ensure that all locks are in locked position and screw is tighten fully before the kid rides the scooter



Caution: Ensure that all locks are in locked position and screw is tighten fully before the kid rides the scooter



STARANDDAISY

Premium Babycare Products



Scan for Installation video



+91-9872399399



care@staranddaisy.in



www.staranddaisy.in