


BABY'S CHARM THE ELEGANT WALKER

HERO FEATURES
 Detachable Toy Tray
 Height Adjustable
 Foot Cushion
 Compact Folding





VISUAL OVERVIEW OF ALL PARTS

Clear breakdown of all the components and their placement within a product.



INCLUDED INVENTORY

The Unboxing Experience




HEIGHT ADJUSTING

Adaptability to your child's growth and developmental stages.


Height Adjustable Lever

Pull the lever provided to adjust height. Change the position to find the best fit for your baby.



STARANDDAISY

Premium Baby Care Products




Scan Now For More Details

"Your Partner in this Beautiful Journey Called Parenting"

www.staranddaisy.in


EASY ASSEMBLY STEPS

Your Comprehensive Baby Walker Setup Guide.




Cushioned Seat Setup

Attach seat plate to the upper body of walker then attach seatplate with cushion as shown.




Upper Body Leg Setup

Turn the walker upside down pull leg outward as shown in figure 1, press it gently until you hear the click sound and pull the handle to unlock it as shown in figure 2, after it unlocks rotate the legs in sideways (anti-clockwise) to extend the legs as shown in figure 3, that's all walker is now unfolded.




Connect Upper Body With Lower Body

Hold the body in upright position now insert it into the lower frame into respective position, connect upper body to the lower frame by pressing the button as shown above.




Footrest Mat Setup

Install the mat within the lower frame as shown in this figure above.



Wheels Setup

Turn the walker upside down and tighten the wheel. Ensure the seal of the wheel should touch the base of the walker.



Toy Bar Setup

Install all toys to their respective positions with hands to fully fix.

Battery Setup

Remove the lid and install three AA sized batteries for power. Let your baby groove to the melodies.